



SNEEZE GUARDEZ

1 I N G E R M S A F E T Y

Freestanding Sneeze Guard Assembly Instructions

Thank you for your purchase! Assembling a sneeze guard purchased from Sneeze GuardEZ is simple and quick! Your sneeze guard comes with all necessary components included.

Each sneeze guard panel will include the following:

- Plexiglas panel
- Aluminum bases w/ 3M VHB Adhesive backing
- Adhesive backed rubber pads (8" strips)

Step 1

After unpacking your Sneeze Guard, lay out all of the included items. Remove the paper masking from the Plexiglas panel and place on a level surface. It is recommended to use a blanket underneath your work surface to avoid scratching the Plexiglas.

Step 2

Remove adhesive backing. Align two "L" brackets -- one on each side -- with the bottom of the bottom of the plexiglas. Once aligned, press firmly to adhere the adhesive. Hold for 10-15 seconds. ****the 3M VHB reaches maximum adhesion after 24hrs.**** Additionally, it is important that you do not touch the adhesive, the oils will drastically reduce its ability to adhere to the Plexiglas.

Step 3

Optional: Peel adhesive backing off of the supplied rubber strips and place on the bottom of each base.

For questions, please contact us at sales@sneeze-guardez.com

****Due to COVID-19 we are unable to accept open package returns at this time****

